

## 3D PRINTING AND DESIGN REFERENCE DOCUMENT

|                        |                |
|------------------------|----------------|
| <b>Document Title:</b> | Document Title |
| <b>Document No.:</b>   | 1716487250     |
| <b>Author(s):</b>      | jattie         |
| <b>Contributor(s):</b> |                |

### REVISION HISTORY

| Revision | Details of Modification(s) | Reason for modification   | Date             | By     |
|----------|----------------------------|---------------------------|------------------|--------|
| 0        | Draft release              | Document description here | 2024/05/23 18:00 | jattie |

# FDM Printer Calibration

Calibrating and tuning your FDM 3D printer is essential to achieve high-quality prints. Here are the steps you can follow:

- **Ensure Everything Is Tight:**
  - Check all bolts and screws on your printer to make sure they are tight. Loose parts can introduce slop into your prints, affecting quality.
  - Properly tension the belts. If your printer doesn't have built-in tensioners, consider printing and using a belt tensioner for better control.
- **Level Your Print Bed:**
  - Proper bed leveling is crucial for good adhesion and consistent layer height.
  - Use an index card or similar material to set the correct distance between the print head and the bed. Adjust the Z-axis end stop variable if needed.
  - Most printers have corner screws for bed leveling.
- **Calibrate Your Z-Offset:**
  - Fine-tune the distance between the nozzle and the bed. This ensures proper first-layer adhesion.
  - Adjust the Z-offset in your printer settings.
- **Measure Your Filament:**
  - Measure the diameter of your filament using calipers.
  - Input the correct filament diameter in your slicer software.
- **Print a Temperature Tower:**
  - A temperature tower helps you find the optimal printing temperature for your filament.
  - Search for a suitable temperature tower model and print it.
- **Calibrate Your Extruder:**
  - Ensure that your extruder is pushing the correct amount of filament.
  - Use a calibration cube or other test prints to fine-tune the extrusion multiplier.
- **Tune Your PID Settings:**
  - PID (Proportional-Integral-Derivative) settings control the heating element.
  - Use PID autotuning or manually adjust the values for consistent heating.
- **Calibrate Your Stepper Motors:**
  - Check that your printer's motors move the correct distance.
  - Print a calibration cube and measure its dimensions to adjust the steps per millimeter.
- **Calibrate the Printing Speed:**
  - Experiment with different print speeds to find the right balance between speed and quality.
  - Adjust speed settings in your slicer.
- **Print a Benchy (or Other Calibration Print):**
  - The Benchy boat is a popular calibration model.
  - It helps identify issues like overhangs, layer adhesion, and surface quality.

Last update:  
2024/05/23  
18:08

02\_printer\_tuning:01\_overview [http://3dfaq.net/02\\_printer\\_tuning/01\\_overview?rev=1716487701](http://3dfaq.net/02_printer_tuning/01_overview?rev=1716487701)

---

Patience and persistence are key during the calibration process. Take your time, make small adjustments, and test your settings with various prints. Happy printing!

From:  
<http://3dfaq.net/> - **3D Printing Wiki**

Permanent link:  
[http://3dfaq.net/02\\_printer\\_tuning/01\\_overview?rev=1716487701](http://3dfaq.net/02_printer_tuning/01_overview?rev=1716487701)

Last update: **2024/05/23 18:08**

